


Diamond Refractive Optics Fabrication by Laser Ablation and at-Wavelength Testing

Sergey Antipov (Euclid Techlabs)

Thomas Roth, Rafael Celestre (ESRF)


Funded by DOE SBIR, PM E. Lessner

s.antipov@euclidtechlabs.com



RXOPTICS GmbH

- A. Snigirev, V. Kohn, I. Snigireva, B. Lengeler, A compound refractive lens for focusing high-energy x-rays, Nature 384 (1996), 49-51
- B. Lengeler, C. Schroer, J. Tümmler, B. Benner, M. Richwin, A. Snigirev, I. Snigireva, M. Drakopoulos, Imaging by parabolic refractive lenses in the hard x-ray range, J. Synchrotron Rad. (1999) 6, 1153-1167
- B. Lengeler, Refractive x-ray lenses: New developments, 2012




Compound Refractive Lens

3

Ultimate Storage Ring – ultra-high brightness

- New generation of synchrotrons MAX IV, ESRF-U, SIRIUS, SPRING-8-U, APS-U
- Round beam (source) – ideal for x-ray microscopy, tomography etc..
- Higher degree of coherence
- APS-U exceeds the capabilities of today's storage rings by 2 to 3 orders of magnitude in brightness, coherent flux, nano-focused flux




- High heat load on the x-ray beamline elements
- Stringent requirements on preservation of coherence



4

Diamond Compound Refractive Lens?

- Low Z
- Single crystal
- Best thermal conductivity
- Outstanding coefficient of linear thermal expansion
- Radiation hard
- Semiconductor



5





Femtosecond laser microfabrication of diamond



Fs- laser: 515nm, 3W, 60kHz, 200fs

6

Ablation Scripting




7



Metrology in-house


Scanning confocal laser microscopy

8



Polishing process

9




Side view: as ablated vs polished

10


Comparison of Scattering at NSLS-II, CHX beamline

- 2D intensity distributions generated by EIGER detector located at ~16 m distance from the lenses @ 9.65 keV for diamond and Be CRLs
 - azimuthally averaged scattering curves
 - 200 x 200 μm^2 aperture before the CRL
- "The low X-ray scattering produced by diamond CRLs is one of its very attractive features, that may allow to extend the range of applications of the CRL optics to the areas / experiments that are very sensitive to background scattering (e.g. where coherent diffractive imaging reconstruction of weakly-scattering samples is performed), where Be lenses are not currently used, or are not considered as the optics of best choice"




13

At-Wavelength Lens Metrology: X-ray speckle vectorial Tracking (XSVT)




14

Radiography and cross-correlation peak




15

Paraboloid fit vs aperture




16

Profile decomposition



17

Correctable profile



Rotationally-symmetric (spherical) aberrations can be corrected by a correction phase plate. In future it may be possible to correct other aberrations. At this point this is difficult given the stringent alignment requirements for non-spherical features.

18

Summary

- Diamond refractive lenses
 - <1um figure error is achieved
 - 300nm roughness as ablated, 20nm roughness polished
- "Coin" - packaging equivalent to industry standard Be-lenses is available

Acknowledgement

- DOE SBIR funding (PM E. Lessner)
- Collaborators:
 - X-Ray Optics group (ESRF)
 - S. Shastri (Material Physics and Engineering, APS, ANL)
 - O. Chubar, L. Wiegart, A. Fluerasu, M. Raktin (NSLS, BNL)
 - W. Grizolli (*now at Lyncean), X. Shi, L. Assoufi (Optics Group, APS, ANL)
 - S. Stoupin (*now at LLNL) (CHESS, Cornell)
 - P. Chow (High Pressure CAT, APS, ANL)

12

Diamond Lens	Optical metrology	17 keV BM05 metrology	Notes
R (apex)	~95.35 um average (on each side)	48.1 um average (96.2 um per side)	Equivalent to Be lens with R=50 and 2R ₀ =450
2R ₀ (aperture)	410 um	350um usable	
d (neck)	19.7 um average		
As-ablated roughness	~300nm		
As-ablated figure error (350um aperture)	0.64um average	1.09um average (for both sides)	0.082um – standard deviation
Polished roughness	~20nm		
Polished figure error	0.91um average	1.19um average (2 sides)	
Form-factor	2-sided lens	Full lens measurement	
Alignment	<3um		

Tested Diamond Lens Quick Stats

