



All-permanent magnet ECR Ion Source DECRIS-PM

**A. Efremov, S. Bogomolov, V. Bekhterev, A. Bondarchenko,
A. Lebedev, V. Loginov, V. Mironov**

JINR, Dubna, Moscow Region, Russia

N. Konev ITT-group, Moscow, Russia


HIAT 2018, Lanzhou, China

OUTLINE


DECRIS PM: Dubna ECR Ion Source made of Permanent Magnets

- ◆ **Goals for DECRIS PM**
- ◆ **Magnetic Structure and unique features**
- ◆ **Commissioning results**
- ◆ **Summary and future plans**

DC-280 Cyclotron



Working diagram of the DC-280



Expected beam parameters of the DC-280

ION	Z	Beam Intensity from ECR		Efficiency of acceleration	Expected beam intensities of (4÷8) MeV/n ions on targets pps
		eμA	pps		
20Ne	3	150	$3 \cdot 10^{14}$	50%	$1.5 \cdot 10^{14}$
40Ar	7	300	$3 \cdot 10^{14}$	50%	$1.5 \cdot 10^{14}$
48Ca	7/9	160	$1.3 \cdot 10^{14}$	50%	$6.2 \cdot 10^{13}$
⁵⁰ Ti	8/9	80	$6.2 \cdot 10^{13}$	50%	$3.1 \cdot 10^{13}$
⁵⁴ Cr	9	125	$8 \cdot 10^{13}$	50%	$4 \cdot 10^{13}$
58Fe	9/10	125	$8 \cdot 10^{13}$	50%	$4 \cdot 10^{13}$
64Ni	10/11	125	$8 \cdot 10^{13}$	50%	$4 \cdot 10^{13}$
70Zn	11/12	100	$5 \cdot 10^{13}$	50%	$2.5 \cdot 10^{13}$
136Xe	22/23	150	$4 \cdot 10^{13}$	50%	$2 \cdot 10^{13}$

Basic requirements for the source design:

minimum energy consumption



All-permanent magnet ion source

high intensity of required ion beams



“Full-size” ion source

Ion source	Nanogan	SuperNanogan	LAPECR2
Frequency [GHz]	14.5	14.5	14.5
Plasma chamber [mm]	28	45	67
Ar ⁸⁺ [eμA]	60	200 (300*)	460
Ar ⁹⁺ [eμA]	20	90 (150*)	355
Weight of PM	90	220	~ 500

The goal was to reproduce parameters of CAPRICE-type RT ECR

Design parameters of DECRIS-PM

Microwave frequency	14.0 – 14.5 GHz
B_{inj}	≥ 1.3 T
B_{min}	0.4 T
B_{extr}	1.0 ÷ 1.1 T
B_r	1.05 ÷ 1.15 T
Plasma chamber ID	70 mm

All PM ECRIS advantages:

- low power consumption
- low pressure in the cooling water system
- simplified operation, etc.


All PM ECRIS drawbacks:

- the fixed distribution of the magnetic field → system should be strongly optimized for the desired operation mode
- strong forces between the individual parts of the system → the correction of the magnetic field after the assembly of the magnetic system is practically impossible without the degaussing of it

But:

the variation in properties of permanent magnets and the variation of easy axis direction for magnets with angular magnetization lead to a difference between the calculated and the actual distribution of the magnetic field.

DECRIS-PM magnet system






Magnetic structure of DERIS-PM.

1÷5 – PM rings; 6, 7 – soft iron rings;
8÷11 – soft iron plates,
12÷14 - auxiliary elements,
15 - hexapole, 16 – coil.

Some features:



- Only magnets with radial and axial magnetization are used (there is no angular magnetization)
- Correction is possible due to changes in soft iron parts





Radial magnetic field

Axial magnetic field



Coil effect





Fig.3 Beam intensity of Ar^{9+} as a function of B_{\min} at the RF power of 100 and 280 W.

Coil parameters:

$$I_{\max} = 300 \text{ A}$$


$$W < 1.6 \text{ kW}$$

$$\Delta P \leq 4 \text{ bar}$$




Adjustment of $B_{\min} \pm 750 \text{ G}$



Cross sectional view of DECRIS-PM



Extraction system




Puller electrode- negatively biased and water cooled




3D view

DECRIS-PM at the test bench




Ar charge state spectra

$\text{Ar}^{8+} = 926 \mu\text{A}$




$\text{Ar}^{11+} = 210 \mu\text{A}$




Kr charge state spectra

$\text{Kr}^{17+} = 125 \mu\text{A}$




$\text{Kr}^{19+} = 50 \mu\text{A}$




Xe charge state spectra

$\text{Xe}^{20+} = 77 \mu\text{A}$




$\text{Xe}^{26+} = 50 \mu\text{A}$




Ion	DECRIIS-PM	LAPECR2	Supernanogan	DECRIIS-3	ECR 4M
Ar ⁸⁺	920	460	300	720	600
Ar ⁹⁺	500	355	150		450
Ar ¹¹⁺	210	166	35	156	200
Ar ¹²⁺	150	62	12	68	100
Xe ²⁰⁺	75	85		84	
Xe ²⁶⁺	50	40	7(Xe²⁵⁺)	23	25(Xe²⁵⁺)

Ca charge state spectra

$\text{Ca}^{9+} = 210 \mu\text{A}$




$\text{Ca}^{11+} = 150 \mu\text{A}$




Mg, Fe and Ti charge state spectra


$\text{Mg}^{9+} = 15 \mu\text{A}$




$\text{Fe}^{10+} = 80 \mu\text{A}$




$\text{Mg}^{5+} = 400 \mu\text{A}$



$^{50}\text{Ti}^{10+} = 72 \mu\text{A}$





Conclusion and future plans.

1. Some very promising results have been obtained from all-permanent magnet ECR ion source DECRIS-PM. The source can provide intense ion beams of gaseous and solid substances. During the tests the operation of the DECRIS-PM ion source was very stable and reproducible. The beam intensity produced by DECRIS-PM meets the requirements of DC-280 cyclotron (for elements from carbon to krypton).
2. We hope to improve the source performance at the high voltage platform due to the following:
 - 3-electrode extraction system (single gap extraction at the test bench)
 - Effect of the additional coil
 - the larger gap between poles of the analyzing magnet (70 mm at the test bench; 110 mm at the HV platform)